

Mitsubishi General-Purpose Programmable Controller Renewal Tool

Conversion Adapter Model

ERNT-ASQT62TCTT ERNT-ASQT62TCTTBW

User's Manual

50CM-D180153-D(1604)

MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED
 HEAD OFFICE:Hulic KUDAN BLDG.1-13-5, KUDANKITA CHIYODA-KU, TOKYO 102-0073, JAPAN
 NAGOYA ENGINEERING OFFICE:139 SHIMOYASHIKI-KO-SHIMOYASHIKI, KASUGAI, AICHI 486-0906, JAPAN

SAFETY PRECAUTIONS

(Always read these precautions prior to use.)

Before using this product, please read this manual carefully and pay full attention to safety to ensure that the product is used correctly.

The precautions presented in this manual are concerned with this product only. For Programmable Controller system safety precautions, refer to the user's manual of the MELSEC-Q series CPU module to be used.

In this manual, the safety precautions are ranked as "WARNING" and "CAUTION."

	WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
	CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or minor injury and/or property damage.

Note that failure to observe the CAUTION level instructions may lead to a serious consequence according to the circumstances. Always follow the precautions of both levels because they are important to personal safety. Please keep this manual in an easy-to-access location for future reference, and be sure to provide the manual to the end user.

Precautions before using

CAUTION

- When making a switch from the MELSEC-AnS Series to the MELSEC-Q Series, be sure to consult user's manual supplied with individual module under the MELSEC-Q Series to confirm differences in various aspects including performance, function, CPU input/output signals and buffer memory addresses between the two series.

Installation Precautions

CAUTION

- Use the Conversion Adapter in the environmental conditions that are specified in the general specification. If the Products are used in any environment beyond the bounds of the general specification, electric shock, fire, malfunction, or damage to or degradation of the Products will result.
- Do not directly touch any conductive parts of Conversion Adapter. Contact will cause malfunction or failure in the system.
- Before attempting to replace the cold junction temperature compensation resistor, always discharge static electricity accumulated in the human body, etc. by touching a grounded (earthed) metal etc. Do not directly touch the conductive area. Failing to do so may cause failure or malfunction.
- Fasten the Conversion Adapter and the Mounting Bracket securely with retaining screws, and tighten the screws by applying torque within specified limits. Loose screws can lead to the dropping of the Conversion Adapter or Mounting Bracket, possibly causing breakage thereof. Excessive tightness of the screws can lead to breakage of the screws, Conversion Adapter, Mounting Bracket, or MELSEC-Q Series Module, possibly causing the dropping, shorting, and malfunction thereof.
- Always check for correct match between MELSEC-Q Series and the Conversion Adapter. Incorrect match can cause damage to the MELSEC-Q Series Module.
- When installing the Conversion Adapter, take care not to get your hand snagged on the Mounting Bracket or the like. Injury may result.
- When installing or removing the MELSEC-Q Series Module complete with a Converter Adapter, be sure to hold it with both hands. Dropping may lead to breakage.

Wiring Precautions

WARNING

- Before attempting to install the Unit or carry out the necessary wiring, make certain that the external power supply, used in the system, is shut off on all three phases. Failure to do so may result in electric shock or damage to the product.
- After installation and wiring, close the terminal block cover before turning on the module for operation. Failure to do so may result in electric shock.

CAUTION

- Carry out wiring for the Conversion Adapter correctly after checking the specification and terminal arrangement for the module used. Connecting a power supply with a different voltage rating or incorrect wiring may cause a fire or failure.
- Tighten the MELSEC-AnS Series terminal installation screws and terminal screw securely by applying torque within the specified limits. Loose screws will cause short circuit, fire or malfunction. Excessive tightening will damage the screws or the Conversion Adapter which in turn will cause dropping of parts, short circuit or malfunction.
- Use care to prevent foreign materials including cuttings and wiring debris from entering the Conversion Adapter or the MELSEC-Q Series Module. These will be cause for fire, failure or malfunction.

Startup and Maintenance Precautions

WARNING

- Do not touch live terminals. There is a danger of electric shock or malfunction.
- Shut off the external power supply for the system in all phases before cleaning or retightening the terminal screws. Failure to do so may result in electric shock or cause the MELSEC-Q Series module to fail or malfunction. Loose screws can lead to dropping, shorting, and malfunction. Excessive tightness of the screws can lead to breakage of the screws, Conversion Adapter, Mounting Bracket, or MELSEC-Q Series Module, possibly causing the dropping, shorting, and malfunction thereof.

CAUTION

- Do not modify the Conversion Adapter or take it apart. Doing so will cause failure, malfunction, personal injury, or fire.
- Do not drop the Conversion Adapter and Mounting Bracket or do not give a strong impact to it. This will cause damage.

Disposal Precautions

CAUTION

- When disposing of the product, treat it as industrial waste.

EMC AND LOW VOLTAGE DIRECTIVES

Compliance to the EMC Directive, which is one of the EU Directives, has been a legal obligation for the products sold in European countries since 1996 as well as the Low Voltage Directive since 1997. Manufacturers who recognize their products are compliant to the EMC and Low Voltage Directives are required to declare that print a "CE mark" on their products.

Authorized representative in Europe

Authorized representative in Europe is shown below.
 Name: Mitsubishi Electric Europe BV
 Address: Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany

1. Overview

This manual describes specifications, handling and other information about the Conversion Adapter "ERNT-ASQT62TCTT, ERNT-ASQT62TCTTBW" available as Renewal Tools for the Mitsubishi General-Purpose Programmable Controller. The Conversion Adapter is a product for effecting conversion to transcend difference in pin assignment between the MELSEC-AnS Series and the MELSEC-Q Series. Before attempting to make a switch from MELSEC-AnS Series to MELSEC-Q Series in your installation, consult the user's manual supplied with individual module under the latter series to learn about how they differ in various aspects including performance and function.

Once you have opened the packaging, verify that it contains the following products.

Product	Quantity	
	ERNT-ASQT62 TCTT	ERNT-ASQT62 TCTTBW (*1)
Conversion Adapter (ERNT-ASQT62TCTT)	1	1
Mounting bracket	1	1
Mounting bracket fixing screw (M3.5×6)	2	2
Terminal block cover	1	1
Cold junction temperature compensation resistor	1	1
Disconnection detector connector conversion cable	-	1
Disconnection detector connector conversion cable installation screw (M3×8)	-	2
This manual	1	1

*1: ERNT-ASQT62TCTTBW is a model (product) name of a set of ERNT-ASQT62TCTT conversion adapter and the disconnection detector connector conversion cable.

2. General Specifications

Item	Specifications					
Operating ambient temperature	0 to 55°C (Maximum surrounding air temperature 55°C)					
Storage ambient temperature	-25 to 75°C					
Operating ambient humidity	5 to 95%RH, non-condensing					
Storage ambient humidity	5 to 95%RH, non-condensing					
Vibration resistance	Compliant with JIS B 3502 and IEC 61131-2	Under intermittent vibration	Frequency: 5 to 8.4Hz	Constant acceleration: 9.8m/s ²	Half amplitude: 3.5mm	10 times each in X, Y, Z directions
		Under continuous vibration	Frequency: 5 to 8.4Hz	Constant acceleration: 4.9m/s ²	Half amplitude: 1.75mm	
Shock resistance	Compliant with JIS B 3502 and IEC 61131-2 (147 m/s ² , 3 times each in 3 directions X, Y, Z)					
Operating atmosphere	No corrosive gases					
Operating altitude *1	0 to 2000m					
Installation location	Inside a control panel					
Overvoltage category *2	II or less					
Pollution degree *3	2					

- *1: Do not use or store under pressure higher than the atmospheric pressure of altitude 0m.
 - *2: This indicates the section of the power supply to which the equipment is assumed to be connected between the public electrical power distribution network and the machinery within premises.
 - *3: This index indicates the degree to which conductive material is generated in terms of the environment in which the equipment is used.
- Pollution level 2 is when only non-conductive pollution occurs. A temporary conductivity caused by condensing must be expected occasionally.

3. Product Specifications

For detail specifications which do not appear in the specification comparison charts contained herein, see the user's manual supplied with the MELSEC-Q Series module you use. Those parts of the specification that differ between the MELSEC-AnS Series and the MELSEC-Q Series are where a switch from the first series to the second is subjected to specification-related restrictions. Check the specification of the devices to be connected for more details.

Furthermore, it is recommended to refer to the "Transition from MELSEC-AnS/QnAS (Small Type) Series to Q Series Handbook (Intelligent Function Modules): L (NA)-08220ENG" issued by Mitsubishi Electric.

The Q64TCTTBWN module cannot be installed to the MELSEC-Q series large type base unit (AnS series size). For replacement using the ERNT-ASQT62TCTTBW conversion adapter, install the Q64TCTTBWN module to the Q□□□ type base unit.


Model	Before replacement MELSEC-AnS Series Model	No. of channels	After replacement MELSEC-Q Series Model	Use of the MELSEC-Q series large type base unit (AnS series size)	Weight (g)
ERNT-ASQT62TCTT	A1S62TCTT-S2	2 channels	Q64TCTTN (Heating-cooling control)	Possible	70
	A1S64TCTRT (Heating-cooling control)				
ERNT-ASQT62TCTTBW (*2)	A1S62TCTTBW-S2	2 channels	Q64TCTTBWN (Heating-cooling control)	Impossible (*3)	160
	A1S64TCTRTBW (Heating-cooling control)				

*2: It is necessary to fix the disconnection detector connector conversion cable that comes with the product using the separately-sold "base adapter (for panel surface installation)" or "conversion adapter DIN rail mounting bracket (for DIN rail installation)". Refer to "5.3 ERNT-ASQT62TCTTBW Installation Procedure".


*3: The MELSEC-Q series module cannot be installed to the MELSEC-Q series large type base unit (AnS series size).

Conversion adapter


1) A1S62TCTT-S2, A1S62TCTTBW-S2



2) A1S64TCTRT, A1S64TCTRTBW



Disconnection detector connector conversion cable



Precaution for wiring

- *1: When the cold junction temperature compensation resistor (CJ) connected to the MELSEC-AnS series module terminal block (TB12 or TB14) comes into contact with adjacent modules, replace the cold junction temperature compensation resistor (CJ) with the one that comes with the product. When the cold junction temperature compensation resistor (CJ) does not come into contact with adjacent modules, replacement is not required.
- *2: Always leave the MELSEC-AnS series module terminals (TB9, TB11, TB17 and TB19) open (unconnected). (They are connected to the MELSEC-Q series module inside the conversion adapter.)
- *3: When using ERNT-ASQT62TCTTBWN, always install the disconnection detector connector conversion cable to the left side, and the conversion adapter to the right side. Installing them the other way around may cause failure of the MELSEC-Q series module.

Specification comparison

Specification	Model	MELSEC-AnS Series		MELSEC-Q Series		
		A1S62TCTT-S2	A1S62TCTTBW-S2	A1S64TCTRT (Heating-cooling control)	A1S64TCTRTBW (Heating-cooling control)	Q64TCTTN (Heating-cooling control)
Control output		Transistor output				Transistor output
Number of temperature input points		2 channels/module				2 channels/module
Supported thermocouples		Refer to the table on the back				Refer to the table on the back
Accuracy	Indication accuracy	Full-scale×(±0.3%±1digit)		Full-scale×(±0.3%±1digit)		Full-scale×(±0.3%)
	Cold junction temperature compensation accuracy (ambient temperature: 0°C to 55°C)	Temperature process value: -100°C or more Temperature process value: -150 to -100°C		Temperature process value: -100°C or more Temperature process value: -200 to -150°C		Temperature process value: -100°C or more Temperature process value: -200 to -150°C
Sampling cycle		500ms/2 channels (constant independently of the number of channels used)				500ms/2 channels (constant independently of the number of channels used)
Heating control output cycle		1 to 100s				1 to 100s
Cooling control output cycle		Refer to the table on the back				Refer to the table on the back
Effect from wiring resistance of 1Ω		Refer to the table on the back				Refer to the table on the back
Input impedance		1MΩ				1MΩ
Input filter		0 to 100s (0: input filter OFF)				0 to 100s (0: input filter OFF)
Sensor correction value setting		-50.00 to 50.00%				-50.00 to 50.00%
Operation at sensor input disconnection		Upscale processing				Upscale processing
Temperature control method		PID ON/OFF pulse		PID ON/OFF pulse		PID ON/OFF pulse or two-position control
PID constants range	PID constants setting	Can be set by auto tuning				Can be set by auto tuning
	Heating proportional band (Ph)	0.1 to 1000.0%				0.0 to 1000.0%
	Cooling proportional band (Pc)	0.1 to 1000.0%				0.1 to 1000.0%
	Integral time (I)	1 to 3600s				0 to 3600s (0:P control and PD control)
Set value setting range	Derivative time (D)	0 to 3600s (0:P control)				0 to 3600s (0:P control and PD control)
	Within the temperature range set by the temperature sensor to be used					
Cooling method setting	Air cooling/water cooling	ON/OFF pulse		ON/OFF pulse		Air cooling/water cooling/Linear
	Output signal	ON/OFF pulse		ON/OFF pulse		ON/OFF pulse
Transistor output	Rated load voltage	10.2 to 30VDC				10 to 30VDC
	Max. load current	0.1A/point, 0.4A/common				0.1A/point, 0.4A/common
	Max. inrush current	0.4A, 10ms				0.4A, 10ms
	Leakage current at OFF	0.1mA or less				0.1mA or less
Insulation method	Between input and grounding:	Transformer insulation		Transformer insulation		Transformer insulation
	Between input and channel:	Transformer insulation		Transformer insulation		Transformer insulation
Heater disconnection detection specifications	Current sensor	—	U.R.D.co.LTD. CTL-12-S36-8 (0.0 to 100.0A) CTL-6-P(-H) (0.00 to 20.00A)	—	U.R.D.co.LTD. CTL-12-S36-8 (0.0 to 100.0A) CTL-6-P(-H) (0.00 to 20.00A)	—
	Input method	—	Multiplexor method A/D conversion	—	Multiplexor method A/D conversion	—
	Input accuracy	—	Full scale×(±1.0%)	—	Full scale×(±1.0%)	—
	Alarm delay count	—	3 to 255	—	3 to 255	—
I/O occupied points		20-point terminal block	20-point terminal block and 8-point connector	20-point terminal block	20-point terminal block and 8-point connector	18-point terminal block
Connection method		0.19A	0.28A	0.33A	0.39A	0.29A
Internal current consumption (5VDC)						0.33A

Precautions for the program

- (1) AnS series module and Q series module differ from each other in the way input/output signals (X, Y) and buffer memory addresses are allocated. Therefore, you need make necessary changes to the sequence program that is used.
- (2) Set "0 (Use standard Terminal Block)" in the "Cold junction temperature compensation selection (address 182)" of the buffer memory of the MELSEC-Q series module.

Point

- (1) When the measured temperature has a margin of error, the sensor compensation function of Q64TCTTN/Q64TCTTBWN can compensate the error.

Thermocouple type	Temperature measurement range	Resolution	Effect from wiring resistance of 1Ω			Temperature measurement range	Resolution	Effect from wiring resistance of 1Ω				
			A1S62TCTT-S2 A1S62TCTTBW-S2	A1S64TCTRT A1S64TCTRTBW	Q64TCTTN Q64TCTTBWN			A1S62TCTT-S2 A1S62TCTTBW-S2	A1S64TCTRT A1S64TCTRTBW	Q64TCTTN Q64TCTTBWN		
R	0 to 1700	1	0.35 μV/Ω	0.15 μV/Ω	0.030(°C/Ω)	0 to 3000	1	0.35 μV/Ω	0.15 μV/Ω	0.054(°F/Ω)		
K	0 to 500, 0 to 800, 0 to 1300 -200.0 to 400.0, 0.0 to 400.0, 0.0 to 500.0, 0.0 to 800.0	0.1				0 to 1000, 0 to 2400 0.0 to 1000.0	0.1				0.005(°C/Ω)	0.008(°F/Ω)
J	0 to 500, 0 to 800, 0 to 1200 0.0 to 400.0, 0.0 to 500.0, 0.0 to 800.0	0.1				0 to 1000, 0 to 1600, 0 to 2100 0.0 to 1000.0	0.1				0.003(°C/Ω)	0.006(°F/Ω)
T	-200 to 400, -200 to 200 0 to 200, 0 to 400	1				0 to 700 -300 to 400	1				0.004(°C/Ω)	0.008(°F/Ω)
S	-200.0 to 400.0, 0.0 to 400.0 0 to 1700	0.1				0 to 700.0 0 to 3000	0.1				0.030(°C/Ω)	0.054(°F/Ω)
B (*4)	MELSEC-AnS Series module 400 to 1800 MELSEC-Q Series module 0 to 1800	1				MELSEC-AnS Series module 800 to 3000 MELSEC-Q Series module 0 to 3000	1				0.038(°C/Ω)	0.068(°F/Ω)
E	0 to 400, 0 to 1000 0.0 to 700.0	1				0 to 1800	1				0.003(°C/Ω)	0.005(°F/Ω)
N	0 to 1300	1				0 to 2300	1				0.006(°C/Ω)	0.011(°F/Ω)
U	0 to 400, -200 to 200 0.0 to 600.0	0.1				0 to 700, -300 to 400	1				0.004(°C/Ω)	0.009(°F/Ω)
L	0 to 400, 0 to 900 0.0 to 400.0, 0.0 to 900.0	0.1				0 to 800, 0 to 1600	1				0.003(°C/Ω)	0.006(°F/Ω)
PL II W5Re/W26Re	0 to 1200 0 to 2300	1	0 to 2300 0 to 3000	1	0.005(°C/Ω) 0.017(°C/Ω)	0.010(°F/Ω) 0.021(°F/Ω)						







*4: The temperature measurement ranges are different between the MELSEC-AnS series and MELSEC-Q series modules. While temperature can be measured within less than 400°C/800°F using the MELSEC-Q series, the accuracy cannot be guaranteed.



4. Mounting and Installation

4.1 Handling Precautions

- Before attempting to install the Unit or carry out the necessary wiring, make certain that the external power supply, used in the system, is shut off on all three phases. Failure to do so may result in electric shock or damage to the product.
- Do not touch live terminals. There is a danger of electric shock or malfunction.
- Do not modify the Conversion Adapter or take it apart. Doing so will cause failure, malfunction, personal injury, or fire.
- Do not touch the energized part of the Conversion Adaptor directly. Contact will cause malfunction or failure in the system.
- Fasten the Conversion Adapter and the Mounting Bracket securely with retaining screws, and tighten the screws by applying torque within specified limits. Loose screws can lead to the dropping of the Conversion Adapter or Mounting Bracket, possibly causing breakage thereof. Excessive tightness of the screws can lead to breakage of the screws, Converter Adapter, Mounting bracket, or MELSEC-Q Series Module, possibly causing the dropping, shorting, and malfunction thereof.
- Use care to prevent foreign materials including cuttings and wiring debris from entering the Conversion Adapter or the MELSEC-Q Series Module. These will be cause for fire, failure or malfunction.
- Do not drop the Conversion Adapter and Mounting Bracket or do not give a strong impact to it. This will cause damage.

4.2 Use Precautions

Item	Use Precautions
Width dimension of module	Because the module is reduced in width dimension (34.5mm→27.4mm) and thus in area available for wiring, check dimensional data before installing the module. <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><MELSEC-AnS Series></p>  <p>34.5mm</p> </div> <div style="text-align: center;"> <p><MELSEC-Q Series></p>  <p>27.4mm</p> </div> </div>
Depth and Height dimension	<p>Installation with the Base Adapter</p> <p>Because the module is increased in depth and height dimension, check dimensional data before installing the module.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div> <p>Installation with the DIN rail</p> <p>Because the module is increased in depth and height dimension, check dimensional data before installing the module.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div>

Item	Use Precautions
Terminal block cover	<p>The terminal block cover for MELSEC-AnS Series is bigger than the width of the MELSEC-Q Series Module. Therefore, it is necessary to replace it with the terminal block cover supplied with the converter adapter.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><MELSEC-AnS Series></p>  <p>34.5mm</p> </div> <div style="text-align: center;"> <p><MELSEC-Q Series></p>  <p>27.4mm</p> </div> </div> <p>Replace the terminal block cover with the one supplied with the Conversion Adapter.</p>


4.3 Installation Environment

The installation environment is the same as MELSEC-Q series CPU Module to use. Refer to the user's manual of the MELSEC-Q Series CPU Module to be used.


5. Part Names and Installation Method

5.1 Mounting Bracket Installation Method


It is necessary to fix the hook of the mounting bracket into the front part (bottom part) of MELSEC-Q series module. Install the mounting bracket before installing the MELSEC-Q series module to the base unit.



5.2 ERNT-ASQT62TCTT Installation Procedure




5.3 ERNT-ASQT62TCTTBW Installation Procedure



5.4 Installation Method

Installation with the Base Adapter	Installation with the DIN rail
Mount the MELSEC-Q Series Base Unit to the Base Adapter. Refer to the Base Adapter's manual for how to install them to the control panel.	Mount the DIN rail mounting adapter manufactured by Mitsubishi Electric to the MELSEC-Q Series Base Unit. For how to install the adapter to the MELSEC-Q Series Base Unit, refer to the QCPU User's Manual.


5.2 ERNT-ASQT62TCTT Installation Procedure	5.3 ERNT-ASQT62TCTTBW Installation Procedure	Description
1	1	Remove the terminal block attached with the MELSEC-Q Series module after loosening the terminal block installation screws (2 places up and down). (When using Q64TCTTBWN, remove the terminal blocks from both right and left slots.) The MELSEC-Q series terminal block (including the cold junction temperature compensation resistor) is not used.  MELSEC-Q Series terminal block installation screw (Secure it in two places, top and bottom.) Secure the mounting bracket to the MELSEC-Q Series module (to the right slot when using Q64TCTTBWN) using the mounting bracket fixing screws (M3.5 × 6). (2 places) Refer to "5.1 Mounting Bracket Installation Method".
2	2	Install the MELSEC-Q Series module to the MELSEC-Q Series Base Unit.
3	3	Install the Conversion Adapter to the mounting bracket, and secure it using the Conversion Adapter installation screws (M3 × 25). (2 places) Precaution Before tightening the installation screws, check that the Conversion Adapter has been securely installed on the MELSEC-Q Series module. Tightening the screws in floating-off state or tilting state will damage the Conversion Adapter installation screws and the mounting bracket.
4	4	Fix the terminal block for the disconnection detector connector conversion cable to the target MELSEC-Q series module (left slot) using the MELSEC-Q series terminal block installation screws (M3.5) (2 places, top and bottom).
5	5	Fix the connector bracket of the disconnection detector connector conversion cable to the base adapter or the conversion adapter DIN rail mounting bracket (bottom) using the disconnection detector connector conversion cable installation screws (M3 × 8) (2 places).
6	6	Connect the MELSEC-AnS series disconnection detector connector to the disconnection detector connector conversion cable.
7	7	Secure the MELSEC-AnS Series terminal block to the Conversion Adapter with the supplied terminal block installation screw (M4). (2 places, top and bottom.)
8	8	Remove the terminal block cover from the MELSEC-AnS Series terminal block and fit the terminal block cover supplied with the Conversion Adaptor in place.

5.5 Tightening Torque

Tighten the module installation screws to the specified torque below. An inappropriate tightening torque could cause the product to fall or result in a short circuit, product failure or malfunction.

Screw Location	Tightening Torque Range
Mounting bracket fixing screw (M3.5×6)	0.68 to 0.92N·m
Conversion Adapter installation screw (M3×25)	0.43 to 0.57N·m
MELSEC-AnS Series terminal block installation screw (M4 screw)	0.78 to 1.18N·m
MELSEC-Q Series terminal block installation screw (M3.5 screw)	0.59 to 0.88N·m
Disconnection detector connector conversion cable installation screw (M3×8)	0.66 to 0.89N·m

6. External Dimensions



Product Warranty Details

Please confirm the following product warranty details prior to product use.

Gratis Warranty Terms and Gratis Warranty Range

If any fault or defect (hereinafter referred to as "Failure") attributable to Mitsubishi Electric Engineering Company Limited (hereinafter referred to as "MEE") should occur within the gratis warranty period, MEE shall repair the product free of charge via the distributor from whom you made your purchase.

■ Gratis Warranty Period

The gratis warranty period of this product shall be one (1) year from the date of purchase or delivery to the designated place. Note that after manufacture and shipment from MEE, the maximum distribution period shall be six (6) months, and the gratis warranty period after manufacturing shall be limited to eighteen (18) months. In addition, the gratis warranty period for repaired products shall not exceed the gratis warranty period established prior to repair.

■ Gratis Warranty Range

The gratis warranty range shall be limited to normal use based on the usage conditions, methods and environment, etc., defined by the terms and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.

Warranty Period after Discontinuation of Production

- MEE shall offer product repair services (fee applied) for seven (7) years after production of the product has been discontinued. Discontinuation of production shall be reported via distributors.
- Product supply (including spare parts) is not possible after production has been discontinued.

Exclusion of Opportunity Loss and Secondary Loss from Warranty Liability

Regardless of the gratis warranty period, MEE shall not be liable for compensation for damages arising from causes not attributable to MEE, opportunity losses or lost profits incurred by the user due to Failures of MEE products, damages or secondary damages arising from special circumstances, whether foreseen or unforeseen by MEE, compensation for accidents, compensation for damages to products other than MEE products, or compensation for other work carried out by the user.

Changes in Product Specifications

The specifications given in the catalogs, manuals and technical documents are subject to change without notice.

This document is a new publication, effective April 2016. Specifications are subject to change without notice.