

## ERNT-AQTB38-E

## 端子台

	TB1
TB2	TB3
TB4	TB5
TB6	TB7
TB8	TB9
TB10	TB11
TB12	TB13
TB14	TB15
TB16	TB17
TB18	TB19
TB20	TB21
TB22	TB23
TB24	TB25
TB26	TB27
TB28	TB29
TB30	TB31
TB32	TB33
TB34 アキ	TB35
TB36 アキ	TB37
TB38 アキ	TB38

TB34, TB36-38は  
アキ端子です。

TB1	1
TB2	20
TB3	2
TB4	21
TB5	3
TB6	22
TB7	4
TB8	23
TB9	5
TB10	24
TB11	6
TB12	25
TB13	7
TB14	26
TB15	8
TB16	27
TB17	9
TB18	28
TB19	10
TB20	29
TB21	11
TB22	30
TB23	12
TB24	31
TB25	13
TB26	32
TB27	14
TB28	33
TB29	15
TB30	34
TB31	16
TB32	35
TB33	17
TB34	36
TB35	18
TB36	37
TB37	19
TB38	

MELSEC-Qシリーズ  
ユニット