

Aシリーズ
端子台

TB2	TB1
TB4	TB3
TB6	TB5
TB8	TB7
TB10	TB9
TB12	TB11
TB14	TB13
TB16	TB15
TB18	TB17
TB19	TB19
TB20	TB21
TB22	TB23
TB24	TB25
TB26	TB27
TB28	TB29
TB30	TB31
TB32	TB33
TB34	TB35
TB36	TB37
TB38	

端子番号	信号名
TB1	Y00
TB2	
TB3	Y01
TB4	
TB5	Y02
TB6	
TB7	Y03
TB8	
TB9	Y04
TB10	
TB11	Y05
TB12	
TB13	Y06
TB14	
TB15	Y07
TB16	
TB17	Y08
TB18	
TB19	Y09
TB20	
TB21	Y0A
TB22	
TB23	Y0B
TB24	
TB25	Y0C
TB26	
TB27	Y0D
TB28	
TB29	Y0E
TB30	
TB31	Y0F
TB32	
TB33	アキ
TB34	アキ
TB35	アキ
TB36	アキ
TB37	DC24V
TB38	0V

外部供給電源は
不要となります。

端子番号	信号名
TB1	Y00
TB2	
TB3	Y01
TB4	
TB5	Y02
TB6	
TB7	Y03
TB8	
TB9	Y04
TB10	
TB11	Y05
TB12	
TB13	Y06
TB14	
TB15	Y07
TB16	
TB17	アキ
TB18	アキ

端子番号	信号名
TB1	Y10
TB2	
TB3	Y11
TB4	
TB5	Y12
TB6	
TB7	Y13
TB8	
TB9	Y14
TB10	
TB11	Y15
TB12	
TB13	Y16
TB14	
TB15	Y17
TB16	
TB17	アキ
TB18	アキ

変換アダプタ

Qシリーズ
端子台
nスロットめ

TB2	TB1
TB4	TB3
TB6	TB5
TB8	TB7
TB10	TB9
TB12	TB11
TB14	TB13
TB16	TB15
TB18	TB17

Qシリーズ
端子台
n+1スロットめ

TB2	TB1
TB4	TB3
TB6	TB5
TB8	TB7
TB10	TB9
TB12	TB11
TB14	TB13
TB16	TB15
TB18	TB17