


A1S68TD
端子台

TB2	TB1
TB4	TB3
TB6	TB5
TB8	TB7
TB10	TB9
TB12	TB11
TB14	TB13
TB16	TB15
TB18	TB17
TB20	TB19

端子番号	信号名
TB1	CH1+
TB2	RTD
TB3	CH1-
TB4	RTD
TB5	CH2+
TB6	CH3+
TB7	CH2-
TB8	CH3-
TB9	CH4+
TB10	CH5+
TB11	CH4-
TB12	CH5-
TB13	CH6+
TB14	CH7+
TB15	CH6-
TB16	CH7-
TB17	CH8+
TB18	FG
TB19	CH8-
TB20	FG

RTD



変換アダプタ

Q68TD-G-H01
Q68TD-G-H02
コネクタ

