


75側コネクタ

サーボアンプ側コネクタ



信号名

READY

RDY COM

INPS

PGO

PGO COM

CLEAR

CLEAR COM

PULSE F+

PULSE F-

PULSE R+

PULSE R-

PULSER A+

PULSER A-

PULSER B+

PULSER B-

DOG

FLS

RLS

STOP

CHG

STRT

COM

COM

信号名

RD

COM

INPS

LZ

LZR

CR

SG

PP

PG

NP

NG

SD