

Mitsubishi Electric Programmable Controller Renewal Tool

Conversion Adapter

Model
ERNT-1JQ64NC



User's Manual

50CM-D180231-C(2211)

MITSUBISHI ELECTRIC ENGINEERING COMPANY LIMITED
HEAD OFFICE: Hulic KUDAN BLDG.1-13-5, KUDANKITA CHIYODA-KU, TOKYO 102-0073, JAPAN
NAGOYA ENGINEERING OFFICE:139 SHIMOYASHIKIHO-SHIMOYASHIKI, KASUGAI, AICHI 486-0906, JAPAN

SAFETY PRECAUTIONS

(Always read these precautions prior to use.)

Before using this product, please read this manual carefully and pay full attention to safety to ensure that the product is used correctly.

The precautions presented in this manual are concerned with this product only. For Programmable Controller system safety precautions, refer to the user's manual of the MELSEC-Q Series CPU Module to be used.

In this manual, the safety precautions are ranked as "WARNING" and "CAUTION."

	WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
	CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or minor injury and/or property damage.

Note that failure to observe the CAUTION level instructions may lead to a serious consequence according to the circumstances. Always follow the precautions of both levels because they are important to personal safety.

Please keep this manual in an easy-to-access location for future reference, and be sure to provide the manual to the end user.

Precautions before using

CAUTION

- When making a switch to the MELSEC-Q Series, be sure to consult user's manual supplied with individual module under the MELSEC-Q Series to confirm differences in various aspects including performance, function, CPU input/output signals between the two modules.

Installation Precautions

CAUTION

- Use the Conversion Adapter in the environmental conditions that are specified in the general specification. If the Products are used in any environment beyond the bounds of the general specification, electric shock, fire, malfunction, or damage to or degradation of the Products will result.
- Do not directly touch any conductive parts of Conversion Adapter. Contact will cause malfunction or failure in the system.
- Fasten the Conversion Adapter securely with retaining screws, and tighten the screws by applying torque within specified limits. Loose screws can lead to the dropping of the Conversion Adapter, possibly causing breakage thereof. Excessive tightness of the screws can lead to breakage of the screws, Conversion Adapter, or MELSEC-Q Series Module, possibly causing the dropping, shorting, and malfunction thereof.
- Always check for correct match between MELSEC-Q Series and the Conversion Adapter. Incorrect match can cause damage to the MELSEC-Q Series Module.
- When installing or removing the MELSEC-Q Series Module complete with a Converter Adapter, be sure to hold it with both hands. Dropping may lead to breakage.

Wiring Precautions

WARNING

- Before attempting to install the Unit or carry out the necessary wiring, make certain that the external power supply, used in the system, is shut off on all three phases. Failure to do so may result in electric shock or damage to the product.

CAUTION

- Carry out wiring for the Conversion Adapter correctly after checking the specification and terminal arrangement for the module used. Connecting a power supply with a different voltage rating or incorrect wiring may cause a fire or failure.
- Tighten the connector screws securely by applying torque within the specified limits. Loose screws will cause short circuit, fire or malfunction. Excessive tightening will damage the screws or the Conversion Adapter which in turn will cause dropping of parts, short circuit or malfunction.
- Use care to prevent foreign materials including cuttings and wiring debris from entering the Conversion Adapter or the MELSEC-Q Series Module. These will be cause for fire, failure or malfunction.

Startup and Maintenance Precautions

WARNING

- Do not touch live connectors. There is a danger of electric shock or malfunction.
- Shut off the external power supply for the system in all phases before cleaning or retightening the screws. Failure to do so may result in electric shock or cause the MELSEC-Q Series Module to fail or malfunction. Loose screws can lead to dropping, shorting, and malfunction. Excessive tightness of the screws can lead to breakage of the screws, Conversion Adapter, or MELSEC-Q Series Module, possibly causing the dropping, shorting, and malfunction thereof.

CAUTION

- Do not modify the Conversion Adapter or take it apart. Doing so will cause failure, malfunction, personal injury, or fire.
- Do not drop the Conversion Adapter or do not give a strong impact to it. This will cause damage.

Disposal Precautions

CAUTION

- When disposing of the product, treat it as industrial waste.

安全注意事项 (使用前请务必阅读)

使用本产品时，请仔细阅读本手册，并充分注意安全，正确地使用产品。本手册中标注的注意事项仅记载了与本产品相关的内容。关于可编程控制器系统的安全注意事项，请参阅所使用的MELSEC-Q系列CPU模块的用户手册。在本安全注意事项中，安全注意事项的等级分为「警告」和「注意」。

	警告	表示错误操作可能造成危险后果，引起死亡或重伤事故。
	注意	表示错误操作可能造成危险后果，引起中度伤害，轻伤及财产损失。

另外，根据情况不同，即使是注意中记载的事项，也可能引发严重后果。不管哪个记载的都是非常重要的内容，请务必遵守。

请妥善保管本手册，以便需要时取阅，并将本手册交给最终用户。

使用前的注意事项

注意

- 替换至MELSEC-Q系列时，为确认性能，功能，CPU对应的输入输出信号等方面的差异，请务必参照MELSEC-Q系列的各模块的手册进行使用。

安装注意事项

注意

- 应在一般规格环境下使用转换适配器。如果在一般规格范围以外的环境中使用转换适配器，可能导致触电，火灾，误动作，产品损坏或性能劣化。
- 请不要直接触摸转换适配器的导电部分。否则可能会造成系统误动作，故障。
- 转换适配器应通过安装螺钉切实地加以固定，安装螺钉应在规定的扭矩范围内切实地拧紧。如果螺钉拧得过松，有可能因掉落而导致转换适配器破损。如果螺钉拧得过紧，有可能造成螺钉，转换适配器及MELSEC-Q系列模块破损，从而导致掉落，短路或误动作。
- 请务必确认MELSEC-Q系列模块和转换适配器的组合是否正确。在错误组合下使用时，可能会导致MELSEC-Q系列模块损坏。
- 在对安装了转换适配器的MELSEC-Q系列模块进行装卸时，请务必用双手拿住产品。否则会因落下而导致损坏。

接线注意事项

警告

- 在进行安装，配线作业等时，必须将系统使用的外部供应电源全部断开后再进行操作。如果未全部断开，有可能导致触电或产品损坏。

注意

- 请确认所使用模块的规格及端子排列后正确地进行转换适配器的接线。如果输入不符合额定值的电压，连接不符合额定值的电源或接错线，可能会导致火灾或故障。
- 连接器安装螺钉应在规定的扭矩范围内切实地拧紧。如果螺钉拧得过松，有可能导致短路，火灾或误动作。如果螺钉拧得过紧，有可能造成螺钉及转换适配器破损从而导致掉落，短路或误动作。
- 请注意不要让切屑或接线头等异物进入转换适配器及MELSEC-Q系列模块内。否则可能会导致火灾，故障，误动作。

启动和维护注意事项

警告

- 在通电状态下请勿触摸导电部分。否则可能导致触电或误动作。
- 在清洁模块或重新紧固螺钉时，必须将系统使用的外部供应电源全部断开后再进行操作。如果未全部断开，有可能导致触电或MELSEC-Q系列模块故障，误动作。如果螺钉拧得过松，有可能导致掉落，短路或误动作。如果螺钉拧得过紧，有可能导致螺钉，转换适配器及MELSEC-Q系列模块破损，从而导致掉落，短路或误动作。

注意

- 请不要拆卸，改造转换适配器。否则可能会导致故障，误动作，受伤或火灾。
- 请勿使转换适配器掉落或受到强烈撞击。否则可能导致破损。

废弃注意事项

注意

- 废弃时请将本产品作为工业废弃物处理。

EMC AND LOW VOLTAGE DIRECTIVES

Compliance to the EMC Directive, which is one of the EU Directives, has been a legal obligation for the products sold in European countries since 1996 as well as the Low Voltage Directive since 1997.

Manufacturers who recognize their products are compliant to the EMC and Low Voltage Directives are required to declare that print a "CE mark" on their products.

Authorized representative in Europe

Authorized representative in Europe is shown below.

Name: Mitsubishi Electric Europe B.V.

Address: Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany

1. Overview

This manual describes specifications, handling and other information about the Conversion Adapter "ERNT-1JQ64NC" available as Renewal Tools for the Mitsubishi Electric Programmable Controller. Before attempting to make a switch to MELSEC-Q Series in your installation, consult the user's manual supplied with individual module under the latter series to learn about how they differ in various aspects including performance and function.

Once you have opened the packaging, verify that it contains the following products.

Product	Shape	Quantity
Conversion Adapter		1
This manual	—	1

2. General Specifications

Item	Specifications	
Operating ambient temperature	0 to 55°C(Maximum surrounding air temperature 55°C)	
Storage ambient temperature	-25 to 75°C	
Operating ambient humidity	5 to 95%RH, non-condensing	
Storage ambient humidity		
Vibration resistance	Compliant with JIS B 3502 and IEC 61131-2	
	Under intermittent vibration	Frequency: 5 to 8.4Hz Constant acceleration: — Half amplitude: 3.5mm Sweep count: 10 times each in X, Y, Z directions
	Under continuous vibration	Frequency: 5 to 8.4Hz Constant acceleration: — Half amplitude: 1.75mm Sweep count: —
		Frequency: 8.4 to 150Hz Constant acceleration: 4.9m/s ² Half amplitude: — Sweep count: —
Shock resistance	Compliant with JIS B 3502 and IEC 61131-2 (147 m/s ² , 3 times each in 3 directions X, Y, Z)	
Operating atmosphere	No corrosive gases	
Operating altitude *1	0 to 2000m	
Installation location	Inside a control panel	
Overvoltage category *2	II or less	
Pollution degree *3	2	

*1 : Do not use or store under pressure higher than the atmospheric pressure of altitude 0m.

*2 : This indicates the section of the power supply to which the equipment is assumed to be connected between the public electrical power distribution network and the machinery within premises. Category II applies to equipment for which electrical power is supplied from fixed facilities.

*3 : This index indicates the degree to which conductive material is generated in terms of the environment in which the equipment is used. Pollution level 2 is when only non-conductive pollution occurs. A temporary conductivity caused by condensing must be expected occasionally.

3. Products Required by the Conversion Adapter

(1) Conversion Adapter Anchor Base (Sold Separately)

The Conversion Adapter Anchor Base secures the bottom of the Conversion Adapter. One anchor base is required per base unit.

Conversion Adapter Anchor Base Model	Specifications	Weight (g)
ERNT-AQF12	12-slot conversion adapter anchor base	590
ERNT-AQF8	8-slot conversion adapter anchor base	410
ERNT-AQF5	5-slot conversion adapter anchor base	275
ERNT-AQF3	3-slot conversion adapter anchor base	185

(2) Base Adapter (Sold Separately)

Both the MELSEC-Q Series Base Unit and the Conversion Adapter Anchor Base can be installed on the Base Adapter without drilling screw holes.

However, drilling screw holes (M5 screws) is required to install the Base Adapter to the panel surface.

For the Base Unit models marked with *1 to *5, two or more Base Adapter models are applicable. Select the most suitable Base Adapter according to the product dimensions.

Base Adapter Model	Installable					Product dimensions WidthxHeight (mm)	Weight (g)
	12 slots	8 slots	5 slots	3 slots	2 slots		
ERNT-AQB38	Q312B					480x240	970
		Q38B(*1)					
ERNT-AQB35		Q38B(*1)				382x240	795
			Q35B				
ERNT-AQB32				Q33B		247x240	675
ERNT-AQB68	Q612B					466x240	930
		Q68B(*2)					
ERNT-AQB65		Q68B(*2)				352x240	790
			Q65B(*3)				
ERNT-AQB62				Q63B	Q52B(*5)	238x240	650
ERNT-AQB58		Q68B(*2)				411x240	870
ERNT-AQB55			Q65B(*3)			297x240	655
			Q55B(*4)				
ERNT-AQB52					Q52B(*5)	183x240	505

